



User Manual

Reverse Tap V20



Preparation

Cautions	3
Name of each part	4
Cautions for installation	5

Operation

Checklist before use	6
Button and displays	7
How to use dispenser	8

Miscellaneous

Whole Structure	15
Cleaning	16
Errors handling	17
Product specification	19



Warning

❖ Power

- Do not use damaged power plug and cord
- Do not touch power plug by wet hands
- Otherwise there might be risk by electrical shock and fire

❖ For installation

- Make sure to close all valves before installation
- Otherwise, high pressure in gas or beverage container may cause injury
- Install product on horizontal and smooth floor

❖ Cleaning

- Do not spray water directly on circuit for cleaning. Do not use benzene, thinner and Sodium Hypochlorite for cleaning
- Otherwise there might be risk by electrical shock and fire

❖ Miscellaneous

- Do not disassemble, repair or alter this product at your discretion
- If you need repair, make sure contact with service center

Cautions

❖ Power management

- Turn off power when lightning strikes or when this product is not used for a long time
- If there occurs strange smell or smoke in the product, make sure to turn off power immediately and contact with service center

❖ Safety check

- Electricity is not available.
- Adapter is too hot
- Electricity flows when product is running.
- Other abnormality or malfunction exist
- Make sure to turn off power switch and make contact with shop where you purchased this product, or service center

❖Front side




❖Outlet





❖ Check list before installation

- Pipe passage in installation table is required
 - Three piping holes are required



- Selection of installation location
 - Make sure that floor is flat and even
 - Make sure to check that floor is able to withstand weight of the product
 - Make sure that electrical connection is available
 - It's required that piping is easy and there is little moisture for installation location
 - Avoid locations where lots of heat exist or too cold location.
- Grounding
 - Grounding is absolutely required to prevent electrical leakage or shock. In case that there is any abnormality on the product
 - No additional grounding is required if receptacle has its own earth terminal (Otherwise a receptacle requires grounding)
 - If there is no grounding on receptacle, make sure to connect grounding line to conducting area of the product and then connect it to metal water tap pipe or grounding line
 - Do not use receptacle whose grounding line doesn't exist. Otherwise micro current leakage may be generated.
 - For more detailed information in connection with installation, consult with shop where you purchased this product or service center

❖ Beverage is not discharged

- Make sure to check KEG and CO2 gas valve before use
- If valve is locked, then beverage is not discharged.
- Make sure to check residual beverage in KEG before use
- If beverage is insufficient, beverage is not discharged.
- Make sure to check residual CO2 before use
- If CO2 is insufficient, beverage is not discharged.

❖ When lots of bubble is generated

- Make sure to check that valve and nozzle is cooled before use
- When this product is first installed, lots of bubble may be generated from nozzle and valve due to differences in temperature.
- Remove bubble in beverage pipe before using this product
- Bubble may be generated due to residual bubble in pipe
- Before using this product, make sure to remove leakage in connecting area of various pipes
- Leakage in pipe connection may generate bubble
- Make sure to fit flow rate by adjusting valve in beverage pipe
- Bubble may be generated due to rapid flow rate
- Use this product after temperature of beverage is cooled
- High temperature of beverage may cause bubble
- Use the product when beverage in KEG is sufficient
- If beverage is insufficient, bubble may be generated.

❖ Configuration Item



1. Top cover



2. Top cover cap



3. Gripper



5. DC power adaptor




6. Hose band



7. Drain hose

■ Display and function switches



1. Capacity

It displays capacity of currently set cup: Large /Medium / Small on OLED



2. Power OFF

By pressing 'STOP' button for more than 2 seconds in waiting mode, power is turned off along with long beep sound



3. Power ON

By pressing 'START' button for more than 2 seconds while power is turned off, power is turned on along with long beep sound and then system is initialized.



4. Start and Stop switches

By pressing 'START' button in manual mode while cup is recognized, selected amount of beer is discharged. When 'STOP' button is pushed in auto or manual mode, discharge of beer is stopped.



5. Mode change and confirm switches

This is a switch to change functions or save changed values



6. Changing set value switch


These switches change values such as amount of discharge



7. OLED display

OLED displays current operation status, mode selection and set values

■ Configuring the default display



1. Amount of discharge (Figure)

In usual status, there is no figure. But if a cup entered, outer shape appears and if beer starts to be poured then internal level is rising up.

2. Displaying accumulated amount

If beer in Keg is completely consumed, then amount of sold beer is displayed and if residual of beer is less than 10%, warning is displayed to prevent bubble of beer from being burst out.

3. AUTO/MANUAL

This indicates current status


4. Set time and amount of discharge (%)

In usual status, set time is displayed and when beer is discharged, then it is expressed in percent

5. Small, Medium, Large

This indicates current set value

■ Stand by Mode



1. Amount of discharge (Figure)

No figure in usual condition


2. Accumulated discharge

This indicates accumulated discharge until now after KEG is replaced. In case of 20,000 CC KGE, when discharge amount exceeds 18,000 CC, then this blinks. Make sure to press button for more than 2 seconds to clear KEG after it is replaced


3. AUTO/MANUAL

This indicates current set value

■ Standby mode



- When a cup is recognized, amount of discharge is displayed in percent instead of set value



- When beer is discharged, bar is rising displaying amount in percent


■ Mode Selection

- Auto / Manual Mode
- Size Mode
- Bubble Mode
- Sales count Mode
- LED Lamp Mode
- Cup Sensor Mode
- KEG Volume Mode
- DEMO Mode

When you push the Right button 1 -> 2 -> 3 -> 4 -> 5 -> 6 -> 7 -> 8 -> 1

When you push the Left button 1 -> 8 -> 7 -> 6 -> 5 -> 4 -> 3 -> 2 -> 1

■ Mode Display




<Auto / Manual>

<Size Setting>

<Bubble Setting>

<Sales count >



<LED Setting>

<Cup Sensor Set>

<KEG Setting>

<DEMO setting>

■ How to set mode



AUTO

- By pressing  button for more than 2 seconds, display is switched into screen change mode
- Initial mode is AUTO/MANUAL mode
- If you want to change set value in mode screen, then push  button, then value is blinking
- and if you push  button, value is set, make sure to confirm changed value by pressing  button again. After all changes are completed, make sure to push  button for more than 2 seconds to save changed values. Otherwise or if power is turned off without saving set values, then the changes are not reflected.

■ Auto / Manual Mode

➤ Auto Mode

When a cup is recognized, then beer is discharged in 0.5 second according to set values: Large / Medium / Small.

➤ Manual mode

Although a cup is recognized, beer is not discharged without pushing 'START' button. By pressing 'STOP' button,



AUTO




Manual

If you select Auto / Manual mode by pushing left or right button, then currently set mode is displayed. By pushing  button, current status is blinking along with beep sound and then system is ready to change mode. By pushing  button, mode is switched into Auto<->Manual mode and then setting is completed along with beep sound by pushing  button. Make sure to save set value by pushing  button long. Even though power is turned off, set value is not changed nor return to original status.

■ Capacity change mode

Amount of discharge is set by Large / Medium / Small. But it can be tuned by tiny amount for each set



- By pushing left and right button  select capacity change mode, then currently set mode is displayed. If you push  button, the system is ready to change setting along with beep sound.
- By pushing  button, mode is switched into Small <-> Medium <-> Large. Select capacity by pushing  button and then time change screen for corresponding capacity is displayed.
- By pushing  time of discharge is changed every 0.1 second and expected amount of discharge is displayed as well.
- Make sure to save set value along with beep sound by pushing  button long. Even though power is turned off, set value is not changed nor return to original status.

■ Changing amount of bubble

When changing bubble amount is set, specified amount is discharged but last amount is discharged being divided into certain amount.




By pushing left and right  button, select bubble amount mode, then currently set mode is displayed. By pushing  button, machine is ready to change set value sounding beep.

Change number by pushing  Left number is changed into +1 <-> +2 <-> +3 <-> 0 <-> -1 <-> -2 <-> -3. This means that +1 indicates once before discharge while -3 indicates three times after discharge. By pushing  button, right number is blinking.

By pushing  time is changed by every 0.1 second from 0.1 second to 0.9 second. Make sure to save set value along with beep sound by pushing  button long. Even though power is turned off, set value is not changed nor return to original status.

■ Bubble Mode


If number is '+', this span is operated forward whereas '0' indicates non-operation



If a cup is recognized, valve is opened in 0.5 second and it is locked in 4.5 second which is calculated by subtracting 1 second (0.5 second x 2 times) from a total time of 5.5 seconds and two times of opening valve for 0.5 seconds after 0.2 seconds (fixed time) is repeated, which amounts to total 5.5 seconds of opening valve.

■ Displaying number of sold cups

This indicates accumulated amount of sold beer until now including whole amount and today's amount.




Accumulated amount

Today's amount

- By pushing left and right button   and select display mode for sold beer, then currently selected mode is displayed. Whenever beer is sold, accumulated sales and today's sale are displayed in number of cups.
- By pushing  button, for more than 2 seconds, it is cleared along with beep sound. When accumulated amount of sold beer is cleared, then today's sold beer is also cleared.
- By pushing  button again, DAY 220 is blinking. by pushing  button for more than 2 seconds, it is cleared along with beep sound. Although today's sold beer is cleared, accumulated amount is not changed.
- Accumulated amount is not changed nor cleared before it is manually cleared although power is turned off.

■ Changing LED illumination

**LED Lamp
Mode 1**

- By pushing left and right button  and select display mode for sold beer, then currently selected mode is displayed.
- By pushing  button, machine is ready to change mode along with beep sound. By pushing  button, mode is changed. Finally by pushing  button, mode is selected along with beep sound. Make sure to save setting by pushing  button long. Setting is not changed although power is turned off.

Mode 0 : Various Color
Mode 1 : Red Color LED
Mode 2 : Green Color LED
Mode 3 : Blue LED
Mode 4 : White LED
Mode 5 : Blink LED

Mode 6 : Yellow Color LED
Mode 7 : Purple Color LED
Mode 8 : Light Green Color LED
Mode 9 : Light blue Color LED
Mode 10 : Light purple Color LED
Mode 11 : Light yellow LED

■ Changing method to recognize cup (sensor)

As number of cup recognition sensor is two, set value for operation can be changed.

**CUP SENSOR
DOUBLE**

- By pushing left and right  button, select illumination change mode, then currently set mode is displayed. If you push  button, the machine is ready to change set value along with beep sound. Mode is changed by pushing  button.
- Make sure to save setting by pushing  button long. Setting is not changed although power is turned off.

DOUBLE Mode

If the machine is set to "DOUBLE", beverage can be discharged only when both sensors are all recognized.

SINGLE Mode

If the machine is set to "SINGLE", beverage is discharged although one of both sensors is recognized.

■ Changing KEG capacity

This enables to set amount of discharge and capacity of KEG



- By pushing left and right  button, select illumination change mode, then currently set mode is displayed.
- If you push  button, the machine is ready to change setting along with beep sounds. You can also change set value by  button
- Finally, if you push  button, then setting is completed along with beep sound. Next make sure to save setting by pushing  button for long time.
- Setting is not changed although power is turned off. 'Changing amount of discharge' enables to change setting of discharging amount. Amount of discharge can be changed every 0.05 CC using  button.
- 'ALARM is changed by every 100 cc. This set value is for changing amount of alarm in waiting screen.
- ** This setting doesn't change amount of discharge but change standard value of discharging amount based on measured value. If you want to change standard value, then push  button for long time, then it is recovered to initial value.

■ Whole Structure



■ Tools



① Drill (if necessary)



② Wrenches



③ + , - Driver



④ Multi scissors



⑤ Knife



⑥ Lighter or torch



❖ How to clean the product

● Auxiliary parts for dispenser

- Clean them by water and neutral detergent
- Clean beverage pipes or replace them regularly (once every 6 month)

● How to disassemble the product for cleaning

- Grab top cover by both hands and unplug it by lifting it up.
- Grab gripper plate by hand and lift it up for unplugging
- Unplug nozzle by rotating it counter-clockwise

● How to clean beverage pipes

- Fill washing container with clean water and connect it with head
- Open Co2 gas valve
- Put a cup to dispenser and let beverage be discharged
- Repeat the above action until clean water is discharged
- Lock CO2 gas valve and remove CO2 in washing container
- Separate head from washing container and put it into clean water

● Reference

- If the product is not used for a long time, drain all beverage inside pipes and wash them using water and dry it.

● Cautions

- Do not spray water on the product directly. Do not clean it with benzene, thinner, Sodium Hypochlorite, alcohol and acetone. Otherwise there might be risk caused by fire or electric shock
- Do not use coarse surface of substance such as brush, loofah and coarse cloths for cleaning dispenser
- Make sure to turn power switch off and then turn it on after cleaning. Otherwise there might be risk caused by fire or electric shock



Symptom	Checks	Treatment
Beverage is not discharged	Is power switch off?	Turn power switch On
	Is adapter power unplugged?	Plug adapter power again
	Is KEG valve locked?	Open valve of KEG
	Is CO2 gas valve locked?	Open CO2 gas valve
	Is flow rate regulator locked?	Open flow rate regulator
	Is head connected?	Connect head to KEG
	Is there beverage in KEG?	Replace it with a KEG including beverage
	Is coil in cooler frozen	Request A/S
	Is a cup well recognized?	Make sure to check operational status for cup recognition sensor
Lots of bubble are created	Is beverage pipe is broken? Or isn't it isolated from heat?	Replace pipe and keep it isolated from heat
	Is pipe connected to sol valve leaked?	Make sure to check fastening of clamp for pipe connection
	Is nozzle temperature high?	Make sure to keep nozzle temperature under proper level
	Is beer KEG significantly swaying during transportation?	Make sure to stabilize it for an hour before use
	Is pressure of CO2 too low?	Adjust the pressure under proper level (30 ~ 55PSI)
	Is flow rate regulation correct?	Adjust flow rate regulator to proper level
	Is gas leaked from head?	Make sure to check head and then re-connect it
Bubble is too scarce	Is CO2 gas pressure too low?	Make sure to check gauge and adjust it under proper level
	Is flow rate regulation incorrect?	Adjust flow rate regulator under proper level

Symptom	Checks	Treatment
Beverage is not cool	Is cooler properly operated?	Make sure to check power of cooler
	Is cooling water insufficient?	Refill cooling water up to a level where coil is soaked
	Is agitating motor malfunctioned?	Request A/S
	Is temperature of KEG high?	Keep KEG under a chilled area
There is a strange smell on beverage	Is pipe connection checked?	Replace pipes with new pipes once every 6 month
	Is pipe cleaned?	Wash it regularly
	Is KEG well preserved?	Replace KEG before use
	Is a cup clean?	Use a clean cup
The machine is not operated although the button is pushed	Button may not be operated if it is touched by wet hands, cleaned by damp cloth, which means that button sensing part is abnormal due to moisture. Make sure to remove moisture on button.	
Screen of LCD monitor is abnormal	Is abnormality still persistent although power is turned off and turned on again?	Request A/S
Main LCD touching is not operated	Is abnormality still persistent although power is turned off and turned on again?	Request A/S



❖ **Default Setting Value**
 • Default setting value are as below


Parameter	Default Setting	Min	Max	Remark
Small Cup On Time	5.8	0	99	sec
Medium Cup On Time	7.5	0	99	sec
Large Cup On Time	11.3	0	99	sec
Bubble Count	0	-3	+3	
Bubble Generation Time	0	0	0.9	sec
Total Cups	0	0	50000	Total sales amount / EA
Daily Cup	0	0	5000	Daily sales amount / EA
Flow Count	0	0	1000000	impeller sign count
LED Mode	0	0	11	LED Mode
OLED Contrast Value	5	0	255	OLED brightness , 0~7 step
Cup Sense Mode	1	0	1	Cup sensor method
Capacity Unit	6.25	0	100	Discharged rate, / cc
Alarm Capacity	18000	0	50000	Alarm value / cc

❖ **Product specification**

Model name	SINGLE	TWIN
Weight of main body	1.5Kg	9Kg
Product dimension	Horizontal (mm)	238mm
	Vertical (mm)	300mm
	Height (mm)	92mm
Rated voltage	DC 24V /1.5A	DC 24 / 2.5A
Power consumption		
Photographs		

- Design and product specifications may be changed for quality improvement without notification
- Auxiliary products may vary depending on each model. If you want to purchase additional auxiliary parts, consult with shop where you purchased this product

Company Information



Reversetap HQ
Technical support
www.reversetap.kr

Customer Center